



Photo courtesy of Michigan DOT

IT'S ALMOST TIME TO INSTALL

The pre-planning is complete and the installation date is scheduled. This checklist will help you make sure you have the necessary tools for the installation of Zoneguard. As always, if you have any questions, please contact us.

REQUIRED ITEMS:

- Lifting Equipment (i.e. excavator, crane, etc.); contact your salesperson if you're unsure your equipment will work.
- Rigging apparatus (chains, cables or slings with at least 3,100 lbs. lifting capacity)
- Two (2) recommended taglines (rope, long straps, etc.)
- 3/4" Wrench for tightening/loosening sliding engagement bar
- Drill with 1 1/2" bit for 12" concrete or 20" asphalt pins

ITEMS THAT MAY COME IN HANDY:

- Piece of lumber
- Spud bar
- Grease gun or other lubricant
- Mallet/hammer (for sliding engagement bars)
- Broom (for debris that impedes barrier placement)